1. Install JDK and set up environment variables.

Windows

Step 1: Download and Install JDK

- 1. Go to the official Oracle JDK download page or use OpenJDK.
- 2. Download the latest version (e.g., JDK 21).
- 3. Run the installer and follow the prompts.

Step 2: Set Environment Variables

- 1. Open Start > type "Environment Variables" > Edit the system environment variables.
- 2. In the **System Properties** window, click **Environment Variables**.
- 3. Under System variables, click New:
 - Variable name: JAVA HOME
 - Variable value: Path to your JDK folder (e.g., C:\Program Files\Java\jdk-21)
- 4. Find the **Path** variable under **System variables**, and click **Edit**.
- 5. Click **New**, then add:
- 6. %JAVA_HOME%\bin
- 7. Click **OK** on all windows.

Step 3: Verify Installation

Open **Command Prompt** and type:

java -version

javac -version

You should see the installed version numbers.